Operation and Service Manual

for HERMetic PRESS

all versions

Note: before using the instrument please read this book.

MED-D
DNV
Certified Company

ISO 9001
CERTIFICATION
Intertek

This document is subject to changes without notice.
Check updates on www.tanksystem.com or contact us at tanksystem@honeywell.com

1. Table of contents

1. TABLE OF CONTENTS 2

2. GENERAL 3

3. RECOMMENDATION FOR SAFE USE 3

4. GENERAL INFORMATION 4

4.1 DISCLAIMER 4
4.2 SHIPMENT NOTE 4
4.3 INITIAL INSPECTION 4
4.4 DOCUMENTATION DISCREPANCIES 4
4.5 WARRANTY 4
4.6 SPARE PARTS 5
4.7 SERVICE AND REPAIR 5

5. WORLDWIDE SERVICE STATIONS NETWORK 7

6. OPERATION 9

7. MAINTENANCE 9

7.1 CARE 9

8. DRAWINGS 9

2. General

The HERMetic Press is designed for verification of pressure/vacuum in closed and inerted tanks.

It has to be used on HERMetic Compact/Deck Valves.

With the HERMetic PRESS connected to the valve connector nipple, the assembly is gas tight.

3. Recommendation for safe use

This Operation and Service Manual is a guide in order to help the user to operate the instrument safely and correctly.

Nevertheless the maker disclaims all responsibility and liability for damage resulting from the use of the equipment regardless of the cause of the damage.

This product and his use is / may be related to international, national, local or company regulations or standards. It is the customer / user responsibility to ensure that the way to use the device complies with such applicable regulations or standards.

This device is a portable product. It must not be permanently installed on the tank and must be disconnected after use and stored in a safe and dry area.

4. General information

4.1 Disclaimer

This manual is designed and written to provide information with regard to the subject matter involved. Enraf Tanksystem SA makes no warranty, express or implied, that it is fit for any purpose whatsoever; or to the absolute sufficiency of the material presented.

Enraf Tanksystem SA assumes no responsibility for any inaccuracies in reproduction or errors in interpretation of any authority. Enraf Tanksystem SA reserves the right to modify or amend this manual, without prior notification, but Enraf Tanksystem SA assumes no responsibility to update or issue corrections.

4.2 Shipment note

The following parts should be included in the shipment:

- 1 instrument;
- 1 Operation and Service Manual.

4.3 Initial inspection

Check the contents of the shipment for completeness and note whether any damage has occurred during transport. Carry out the “Initial test before installing the instrument” to verify the good functioning. If the contents are incomplete, or if there is damage, do not use the device. A claim should be filled with the carrier immediately, and Enraf Tanksystem SA Sales or Service organization should be notified in order to facilitate the repair or replacement of the instrument.

4.4 Documentation discrepancies

The design of the instrument is subject to continuous development and improvement. Consequently, the instrument may incorporate minor changes in detail from the information contained in the manual.

4.5 Warranty

12 months after installation but max. 18 months after delivery ex works.

The Vendor undertakes to remedy any defect resulting from faulty design materials or workmanship. The Vendor's obligation is limited to the repair or replacement of such defective parts by his own plant or one of his authorized service stations. The Purchaser shall bear the cost and risk of transportation of defective parts and repaired parts supplied in replacement of such defective parts.

This warranty does not apply to those items which by their nature are subject to deterioration or consumption in normal service, and which must be cleaned, or replaced on a routine basis.

When returned to Enraf Tanksystem SA equipment must be contamination-free. If it is determined that the Purchasers equipment is contaminated, it will be returned to the Purchaser at the Purchasers expense. Contaminated equipment will not be repaired, replaced, or covered under any warranty until such time that the Purchaser decontaminates the said equipment.

The Purchaser shall notify by fax, telex or in writing of any defect immediately upon discovery, specifying the nature of the defect and/or the extend of the damage caused thereby.

Where no other conditions have been negotiated between the Vendor and the Purchaser "General Conditions 188" of United Nations shall apply.

Unauthorized repair or component replacement by non original spare parts by the Purchaser will void this guarantee and may impair the good functioning of the instrument.

This warranty is expressly in lieu of any and all other warranties and representations expressed or implied, and all other obligations or liabilities on the part of the Vendor (Enraf Tanksystem SA) including but not limited to, the warranty of merchantability or fitness for a particular purpose.

In no event shall Enraf Tanksystem SA be liable for indirect, incidental or consequential loss or

damage or failure of any kind connected with the use if its products or failure of its products to function or operate properly.

Enraf Tanksystem SA do not assume the indemnification for any accident or damage caused by the operation of its product and the warranty is limited to the replacement of parts or complete goods.

4.6 Spare parts

When ordering spares identify the spare part by TS number and description. Refer to section “Drawings”.

Some spares might be repairable; in this case send part to any authorized service center or to the factory.

In case of urgency replacement units can be available while stocks last.

4.7 Service and Repair

The customer should take care of the freight and customs clearance charges. If units are sent on "freight collect " the charges will be invoiced to the customer.

When returning units or parts for repair to the factory please fill out a service request form (see next page).

Service Request

Customer's address: .....
.....
.....
.....
.....

Telephone: .....

Telex: .....

Fax: .....

Type of unit or part: .....
.....

.....

Short description of defective unit or part: .....
.....
.....
.....

Do you want a quotation before repair is started:.....yes / no.....

Repaired unit has to be returned to the following address:

.....
.....
.....
.....
.....

5. Worldwide Service Stations network

The updated list can be found on our website www.tanksystem.com

COUNTRY	ADDRESS	TELEPHONE/FAX/E-MAIL
SWITZERLAND	ENRAF TANKSYSTEM SA 2, rue de l'Industrie CH-1630 BULLE	Tel : +41-26-91 91 500 Fax : +41-26-91 91 505 Tanksystem@honeywell.com
CANADA	PYLON ATLANTIC A Div. Of Pylon Electronics Inc. 31 Trider Crescent., DARTMOUTH, N.S. B3B 1V6	Tel : +1-902-4683344 Fax : +1-902-4681203 halifax_csr@pylonelectronics.com
CHINA	HUA HAI EQUIPMENT & ENGINEERING CO LTD Factory 7, Lane 1365, East Kang Qiao Road Kang Qiao Industrial Zone, Pu Dong SHANGHAI, P.C. 201315	Tel : +86-21-68183183 Fax : +86-21-68183115 huahaish@huahaiee.com
GERMANY	CHRISTIAN BINDEMANN MARINE TECHNICAL SERVICES Antonie-Möbis-Weg 4 HAMBURG 2523	Tel : +49-40-41918846 Fax : +49-40-41918847 service@mkecb.com
GREECE	SPANMARIN 86, Filonos Street GR-185 36 PIRAEUS	Tel : +30-210-4294498 Fax : +30-210-4294495 spanmarin@ath.forthnet.gr
JAPAN	DAIWA HANBAI CORPORATION LTD 2-10-31, Mitejima, Nishiyodogawa-ku OSAKA 555-0012	Tel : +81-6-64714701 Fax : +81-6-64729008 daiwa471@silver.ocn.ne.jp
KOREA	World Ocean CO., LTD Rm1001, Hae-deok Bldg., 1212-11 Choryang-dong Dong-Gu BUSAN	Tel : +82-51-462-2554/5 Fax : +82-51-462-0468 info@worldocean.co.kr
MEXICO	URBAN DEL GOLFO SA DE CV Julian Carrillo No. 709 Nte. COL. LOS MANGOS 89440 Cd. MADERO, Tamps, MEXICO	Tel : +52-833-2170190 Fax : +52-833-2170190 urbansa@prodigy.net.mx
NETHERLANDS & BELGIUM	B.V. TECHNISCH BUREAU UITTENBOGAART Brugwachter 13 NL-3034 KD ROTTERDAM	Tel : +31-10-4114614 Fax : +31-10-4141004 info@tbu.nl

The updated list can be found on our website www.tanksystem.com

COUNTRY	ADDRESS	TELEPHONE/FAX/E-MAIL
PORTUGAL	CONTROLIS, Lda. Rua Conceição Sameiro Antunes, 26-E Cova da Piedade 2805-122 – Almada	Tel : +351-21-2740606 Fax : +351-21-2740897 controlis.port@gmail.com
RUSSIA	NPP "GERDA" Vilisa Latsisa str. 17 Building 1 125480 MOSCOW	Tel : +7-495-7558845 Fax : +7-495-7558846 info@gerda.ru
SINGAPORE	HUBBELL INT'L (1976) PTE LTD 322 Thomson Road SINGAPORE 307665	Tel : +65-6-2557281 Tel : +65-6-2550464 Fax : +65-6-2532098 hubbell@mbox2.singnet.com.sg
SPAIN	E.N.I. Electronica y Neumatica Industrial, S.A. C/Jon Arrospide, 20 (Int.) 48014 BILBAO	Tel : +34-94-4746263 Fax : +34-94-4745868 eni.tecnica@eni.es
SWEDEN	INSTRUMENTKONTROLL Lars Petersson AB Varholmsgatan 1 414 74 GÖTEBORG	Tel : +46-31-240510 Tel : +46-31-240525 Fax : +46-31-243710 Info@instrumentkontroll.se
TURKEY	YEDI DENIZ Setustu, Izzetpasa Yok.1 TR 34427 Kabatas ISTANBUL	Tel : +90.212.251 64 10 / 3 lines Fax : +90.212.251 05 75 servicestation@yedideniz.net dmgistanbul@yahoo.com
UNITED ARAB EMIRATES	MARITRONICS TRADING L.L.C. P.O. Box 6488 Shed # 72, Jadaf Ship Docking Yard DUBAI	Tel : +971-4-3247500 Fax :+971-4-3242500 service@maritronics.com
UNITED KINGDOM	ENERGY MARINE (INTERNATIONAL) LTD. 12 Clipstone Brook Industrial Estate Cherrycourt Way LEIGHTON BUZZARD, BEDS, LU7 4TX	Tel : +44-1525-851234 Fax :+44-1525-852345 info@engmar.com
U.S.A / TEXAS	HONEYWELL HERMETIC 4522 Center Street DEER PARK, TX 77536	Tel : +1-281-930 1777 Fax : +1-281-930 1222 Toll free call in the USA: 1-800-900 1778 hermetic@honeywell.com

6. Operation

1. install the HERMetic PRESS on the HERMetic valve via the quick coupling device.
2. Open the valve. The HERMetic PRESS is then in direct contact with the tank atmosphere, and pressure or vacuum is indicated on the manometer, which is graduated from - 1500 to + 2500 MM water column.
3. Read the pressure.
4. Close the valve.
5. Disconnect the HERMetic PRESS.
6. Clean the HERMetic PRESS before the next check.

7. Maintenance

7.1 Care

For long service life, keep the HERMetic Press clean and well lubricated and, when not in use, store it in a dry and protected location.

To adjust the zero of the manometer, remove the rubber blanket and the top cover. Turn the adjusting screw located in the centre of the manometer.

When ordering spare parts, always state the drawing and the item number.

8. Drawings

	ND	TS	DESCRIPTION
	30275	10069	Press stainless steel 1” mmWC
	30415	10020	Press 1” mmWC
	41160	22566	Adaptor 1”/2”







Item	Qty	Weight	Description	Material	TS	ND
1	1	513.2	Storage tube 1" Oxy, Press, Dip 1	-	16010	30595
2	1	485.0	Gauge G 1/2" gratuated mmWC	1.4571	17503	40801
3	1	125.1	Protection gauge color blue	NBR	17502	41296
4	1	1.0	O-Ring ø 29,75 x 3,53	FFKM	11147	
5	1	0.2	Label " Enraf Tanksystem"	-	50006	40343
6	1	0.1	Label " PRESS "	-	50008	40346

TOLERANCES UNLESS OTHERWISE SPECIFIED

Norm.Size	Over		6	30	100	300	1000	Angles
Fit	To	6	30	100	300	1000	2000	
Fine	±	0,05	0,1	0,15	0,2	0,3	0,5	0,1°

REMOVE ALL BURRS AND SHARP EDGES

Weight: 1124.6 Eff.

ISSUE 3 : 21.05.2012

Drawn: CPI 05.08.2011

Control:

1:2

MPSA

Replacement for: ND

Replaced by: ND

HERMetic Press

Press stainless steel 1" mmWC

TS 10069

ND 30275

REF ND

This drawing is our property and must not without our permission be copied or made available to others. The receiver is responsible for every misuse.

Enraf Tanksystem SA
RUE DE L'INDUSTRIE 2 CH-1630 BULLE
Tel. +41 26 91 91 500 - Fax +41 26 91 91 505







Item	Qty	Weight	Description	Material	TS	ND
1	1	513.2	Storage tube 1" Oxy, Press, Dip 1		16010	30595
2	1	545.0	Gauge G 1/2" gratuated mmWC		17501	40800
3	1	125.1	Protection gauge color blue	NBR	17502	41296
4	1	1.0	O-Ring ø 29,7 x 3,53	FKM	11132	
5	1	0.2	Label " Enraf Tanksystem"		50006	40343
6	1	0.1	Label " PRESS "	-	50008	40346

TOLERANCES UNLESS OTHERWISE SPECIFIED

Norm.Size	Over		6	30	100	300	1000	Angles
Fit	To	6	30	100	300	1000	2000	
Fine	±	0,05	0,1	0,15	0,2	0,3	0,5	0,1°

REMOVE ALL BURRS AND SHARP EDGES

Weight: 1184.6 Eff.

1:2

ISSUE 3 : 21.05.2012

MPSA

Drawn: CPI 05.08.2011

Control:

Replacement for: ND

Replaced by: ND

HERMetic Press

Press 1" mmWC

TS 10020

ND 30415

REF ND

This drawing is our property and must not without our permission be copied or made available to others.
The receiver is responsible for every misuse.

Enraf Tanksystem SA
RUE DE L'INDUSTRIE 2 CH-1630 BULLE
Tel. +41 26 91 91 500 - Fax +41 26 91 91 505



Item	Qt	Weight	Description	Material	TS #	ND #
1	1	401	Connector 1" - 2" FKM	-	22563	41032
2	1	5	S Holder	AISI 304	11902	40537
3	1	7	Short cable assy	-	55135	40999

TOLERANCES UNLESS OTHERWISE SPECIFIED

Norm.Size	Over		6	30	100	300	1000	Angles
Fit	To	6	30	100	300	1000	2000	
Fine	±	0,05	0,1	0,15	0,2	0,3	0,5	0,1°

REMOVE ALL BURRS AND SHARP EDGES

Weight: 413 Th. 410 Eff.

ISSUE 1 : 4.1.2001

1:1

MPSA 3110

Drawn: cpi 04.01.2001

Control:

Replacement for: ND

Replaced by: ND

Modification | Visa | Date | Is

Valves

Adaptor 1"-2" with short cable

TS 22566

ND 41160

REF ND

This drawing is our property and must not without our permission be copied or made available to others. The receiver is responsible for every misuse.

Enraf Tanksystem SA
RUE DE L'INDUSTRIE 2 CH-1630 BULLE
Tel. +41 26 91 91 500 - Fax +41 26 91 91 505